













- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod














A	B	C (mm)		D
1	M130-004	396	953	1/1
2	M130-103	1046	354	1/1
3	M130-104	1046	354	1/1
4	M130-205	522	354	1/1
5	M130-206	522	354	1/1
6	M130-304	488	334	1/1
7	M130-573	959	60	1/1
8	M130-575	523	60	1/1
9	M130-9903	1055	497	1/1





1 






2 






3



4



8



Pflegehinweis!

Bitte nur mit einem Staubtuch (kein Microfasertuch) oder einem feuchten Lappen reinigen. KEINE scheuernden Putzmittel verwenden!

Wskazówka dotycząca pielęgnacji!

Proszę czyścić tylko suchą lub lekko wilgotną szmatką do kurzu. Nie używać żadnych środków szorstkich!

